








## Assembly instructions for speaker base Speaker SB-MP481

**ATTENTION: DO NOT DISCARD PACKAGING. PARTS INSIDE**

Assembly hardware		Tools required	
<div>A</div> <div></div> <div>Wood dowels (x2)</div>	<div>B</div> <div></div> <div>Screws (x2)</div>	<div></div> <div>Hammer</div>	<div></div> <div>Phillips Screwdriver</div>
<div><b>STEP 1</b></div> <div></div> <div>• Insert the wood dowels into the holes shown. If necessary, tap slightly with a hammer.</div>		<div><b>STEP 2</b></div> <div></div> <div>• To prevent damage to the speaker, carefully lay the speaker on top of a soft cloth or blanket, before attaching the base.</div>	
<div><b>STEP 3</b></div> <div></div> <div><b>Note:</b> • Fully insert the wood dowels into the holes indicated by the arrows at the bottom of the speaker.</div> <div>• Attach the speaker base to the bottom of the speaker. Use 2 screws (included). Do not overtighten the screws. Carefully lift the speaker to vertical position.</div>			

LU

Panasonic Consumer Electronics  
Company, Division of Matsushita  
Electric Corporation of America  
One Panasonic Way Secaucus,  
New Jersey 07094  
<http://www.panasonic.com>

Panasonic Sales Company,  
Division of Matsushita Electric of  
Puerto Rico, Inc. ("PSC")  
Ave. 65 de Infantería, Km. 9.5  
San Gabriel Industrial Park, Carolina,  
Puerto Rico 00985

En